


## ■ Function

- Current Time < hr , min , sec >
  - 24 hr / 12hr switchable
  - Red dot appears on PM when 12hr mode
- Date < month , date >
- Current Time → Press B button once briefly
- Date → Press B button twice briefly



## ■ How to set the time and date

PLEASE NOTE : During setting, the display will be turned off after interval of 5 seconds. In this case, please start the setting procedure again from the beginning.

Press and hold the button to fast forward.

- 1 : When the display is off, press A button twice briefly.  
 In the "Time Mode" , press B button, the "Year" starts flash.  
 Press B button to set the year.  
 The year will be forwarded to 2099, and then back to 2000.
- 2 : Press A button once briefly.  
 In the "Month Mode" , press B button to set the month.
- 3 : Press A button once briefly.  
 In the "Date Mode" , press B button to set the date.
- 4 : Push A button once briefly.  
 In the "Time Mode" , press B button to set the time.  
 ※When you set the time pushing tB button,  
 "A" , "P" , and "H" appears on the screen.  
 "A" shows : a.m. in 12-hour format.  
 "P" shows : p.m. in 12-hour format.  
 "H" shows : 24-hour format
- 5 : Press A button once briefly.  
 In the "Minutes Mode" , press A button to set the minutes.  
 5 seconds after setting the minutes, the screen turns off.